

INSTALLATION INSTRUCTIONS FOR TEAK SHOWER SEAT WITH SWING DOWN LEGS

IMPORTANT: PROPER WALL BACKING MATERIAL AND MOUNTING HARDWARE MUST BE USED TO MOUNT THIS SHOWER SEAT AS REQUIRED BY A.D.A. GUIDELINES. MTI DOES NOT INCLUDE HARDWARE DUE TO VARIETY OF APPLICATIONS.

1. Carefully remove the seat from the shipping carton.
2. Place seat in desired location with mounting flanges firmly against the wall.
3. Lower seat and legs and level unit by adjusting the rubber feet to the desired mounting height (17"-19").
4. With the mounting flanges firmly against the wall, mark the location of the three holes in each flange.
5. Drill the appropriate sized holes in the locations just marked. Tightly secure the two flanges to the wall using sufficient mounting hardware and attaching to proper in-wall backing material suitable for your specific application.
6. Place the seat in the down position and make any necessary final adjustments to the adjustable rubber feet. With the feet resting firmly on the floor, tighten locknuts securely before using seat.

INSTALLATION INSTRUCTIONS FOR TEAK SHOWER SEATS WITHOUT SWING DOWN LEGS

IMPORTANT: PROPER WALL BACKING MATERIAL AND MOUNTING HARDWARE MUST BE USED TO MOUNT THIS SHOWER SEAT AS REQUIRED BY A.D.A. GUIDELINES. MTI DOES NOT INCLUDE HARDWARE DUE TO VARIETY OF APPLICATIONS.

A.D.A. REGULATIONS REQUIRE THE HEIGHT OF THE SEAT TO BE A MINIMUM OF 17" AND A MAXIMUM HEIGHT OF 19" ABOVE THE FLOOR.

USE THE FOLLOWING DIRECTIONS IN CONJUNCTION WITH THE TEMPLATE DIAGRAM PROVIDED. THE TEMPLATE IS NOT TO SCALE AND SHOULD BE USED ONLY AS A GUIDE.

1. The template dimensions are for our 22" wide seat. If your seat is other than 22" do NOT use the measurements on the enclosed template!
2. Determine the seat height and approximate location for final installation. Scribe a horizontal, straight line across the mounting wall for the height of the top of the seat.
3. Select and scribe a vertical center line where seat is to be installed. This will give you the center of the seat. This line will pass through your horizontal line and should be at least 10" long.
4. From the horizontal line, come down 3-5/8" on the vertical center line and scribe a horizontal line for mounting the seat flanges. The line will need to be about 16" wide.
5. Line up center of the flanges with horizontal line just marked and mark the three screw holes on each side.
6. To mark locations for the sliding leg bracket, measure 2-1/4" below the horizontal line from step #5 at the center line. Use the bracket for a template and mark the two top holes and one lower hole. The two top holes should be equally spaced from your vertical center line.
7. Using the appropriate size drill bit for your fastener hardware, drill the three mounting holes for each of the right and left hinge bracket flanges, plus the three holes for the sliding leg bracket.
8. Holding the seat assembly in an upright and raised position against the mounting wall, tightly secure the two hinge bracket flanges to the wall AND INTO PROPER BACKING MATERIAL, using mounting hardware suitable for your specific mounting applications.
9. Slip the lower horizontal portion of the leg tubing into the sliding leg bracket and tightly secure the bracket to the wall AND INTO PROPER BACKING MATERIAL, using mounting hardware suitable for your specific mounting application.
10. Check seat for level, proper operation and weight bearing. The seat is designed to hold a maximum of 350 lbs.

TEAK CARE AND CLEANING

Teak furniture, when left untreated, will fade to a natural silver-gray color. Many individuals love the natural color transformation, which does not affect the durability of the teak furniture or the wood itself.

If you prefer to maintain the smooth finish and natural golden brown color, teak oil may be used. You will need to apply approximately every three months, in addition to occasionally sanding the surface. Initially, several coats will be required, as the wood soaks up the oil. Follow the directions on the product label for best results.

MTI recommends the mildest cleaner possible for the job. A mild solution of liquid laundry detergent (such as Wisk) and chlorine bleach mixed into a gallon of warm water will clean most teak products. Apply this mixture with a stiff brush, and scrub lightly with the grain. Leave it on the wood for several minutes to give the detergent time to suspend the dirt and the bleach time to lighten the wood, then rinse thoroughly, scrubbing lightly with the grain.

TEAK PRODUCTS RESIDENTIAL WARRANTY

Teak Shower Trays and Hidden Drain Covers; Sink Trays

Teak Shower Trays, Hidden Drain Covers and Sink Trays from MTI Whirlpools are warranted against defects in material and workmanship for a period of ten years from date of purchase. They are handcrafted of the finest teak and manufactured to MTI's specifications. During the warranty period, if your teak shower tray becomes unusable due to any defect in workmanship, please contact the MTI service department at 800-783-8827. Proof of purchase required.

Teak Seats

Teak Seats from MTI Whirlpools are warranted for parts only against defects in material and workmanship for a period of five years from date of purchase. They are handcrafted of the finest teak and manufactured to MTI's specifications. During the warranty period, if your teak shower seat becomes unusable due to any defect in workmanship, please contact the MTI service department at 800-783-8827. Proof of purchase required.

TEAK PRODUCTS COMMERCIAL WARRANTY

Teak Shower Trays and Hidden Drain Covers; Sink Trays

Teak Shower Trays, Hidden Drain Covers and Sink Trays from MTI Whirlpools are warranted against defects in material and workmanship for a period of two years from date of purchase. They are handcrafted of the finest teak and manufactured to MTI's specifications. During the warranty period, if your teak shower tray becomes unusable due to any defect in workmanship, please contact the MTI service department at 800-783-8827. Proof of purchase required.

Teak Seats

Teak Seats from MTI Whirlpools are warranted for parts only against defects in material and workmanship for a period of one year from date of purchase. They are handcrafted of the finest teak and manufactured to MTI's specifications. During the warranty period, if your teak shower seat becomes unusable due to any defect in workmanship, please contact the MTI service department at 800-783-8827. Proof of purchase required.

